



RTK Bootcode

Agenda

- Build Boot loader
- On-Chip Recovery mode
- Upgrade Boot loader
- Rescue System
- Dual Firmware Boot
- Customize kernel boot arguments
- Customize reserved memory for transcoding



Build Boot loader RTD129x SPI

- U-Boot
- Path: SDKRelease/Bootcode/U-Boot64
- Build script: build.sh
- Usage:
 - ./build.sh RTD129x_spi
- Output:
 - Bootcode/U-Boot64/DVRBOOT_OUT/RTD129x_spi
 - (1) Bootloader with burning program
 - \$(CHIP_VER) RTD1295_hwsetting_\${DDR}-nas-RTD1295_spi.bin
 - (2) HWsetting
 - hw_setting/\${CHIP_VER} RTD1295_hwsetting_BOOT\${DDR}.bin



Build Boot loader RTD129x eMMC

- U-Boot
- Path: SDKRelease/Bootcode/U-Boot64
- Build script: build.sh
- Usage:
 - ./build.sh RTD129x_emmc
- Output:
 - Bootcode/U-Boot64/DVRBOOT_OUT/RTD129x_emmc
 - (1) Bootloader with burning program
 - \$(CHIP_VER)_hwsetting_\$(DDR)-nas-\$(CHIP)_spi.bin
 - (2) HWsetting
 - hw_setting/\$(CHIP_VER)_hwsetting_BOOT\$(DDR).bin


Build Boot loader – RTD1619 SPI

- U-Boot
- Path: SDKRelease/Bootcode/U-Boot64
- Build script: build.sh
- Usage: ./build.sh RTD16xx_emmc
- Output:
 - SDKRelease/Bootcode/U-Boot64/DVRBOOT_OUT/RTD16xx_emmc/
 - (1) Bootloader with burning program
 - A01-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - (2) Bootloader
 - 1. A01-Recovery-uda-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - 2. A01-Recovery-boot-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - (3) HWsetting
 - hw_setting/0001-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin



Build Boot loader – RTD1619 eMMC

- U-Boot
- Path: SDKRelease/Bootcode/U-Boot64
- Build script: build.sh
- Usage: ./build.sh RTD16xx_emmc
- Output:
 - SDKRelease/Bootcode/U-Boot64/DVRBOOT_OUT/RTD16xx_emmc/
 - (1) Bootloader with burning program
 - A01-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - (2) Bootloader
 - 1. A01-Recovery-uda-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - 2. A01-Recovery-boot-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - (3) HWsetting
 - hw_setting/0001-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin



On-Chip Recovery mode – RTD 129x SPI

- This mode is used for bootloader recovery when the bootloader inside is corrupted
- Hyperterm is recommended to use
- Press **ctrl+q** when booting up until following console appear
 - d/g/r>
- Press **h** and then transfer Hwsetting**(3)** by y-modem
 - hw_setting/\${CHIP}_hwsetting_BOOT_\${DDR}.bin
- Press **s**, then enter
 - 98007058
 - 01500000
- Press **d** and then transfer bootloader**(2)** by y-modem
 - \${CHIP}_VER_hwsetting_BOOT_\${DDR}-nas-\${CHIP}_spi.bin
- Press **g** to start recovery process

On-Chip Recovery mode – RTD129x eMMC

- This mode is used for bootloader recovery when the bootloader inside is corrupted
- Hyperterm is recommended to use
- Press **ctrl+q** when booting up until following console appear
 - d/g/r>
- Press **h** and then transfer Hwsetting**(3)** by y-modem
 - hw_setting/\$(CHIP)_hwsetting_BOOT_\$(DDR).bin
- Press **s**, then enter
 - 98007058
 - 01500000
- Press **d** and then transfer bootloader**(2)** by y-modem
 - \$(CHIP_VER)_hwsetting_BOOT_\$(DDR)-nas-\$(CHIP)_emmc.bin
- Press **g** to start recovery process



On-Chip Recovery mode – RTD 16xx SPI

- This mode is used for bootloader recovery when the bootloader inside is corrupted
- Hyperterm is recommended to use
- Press **ctrl+q** when booting up until following console appear
 - d/g/r>
- Press **h** and then transfer Hwsetting(3) by y-modem
 - hw_setting/0001-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-spi.bin
- Press **d** and then transfer bootloader(2) by y-modem
 - A01-Recovery-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-spi.bin
- Press **g** to start recovery process



On-Chip Recovery mode – RTD16xx eMMC

- This mode is used for bootloader recovery when the bootloader inside is corrupted
- Hyperterm is recommended to use
- Press **ctrl+q** when booting up until following console appear
 - d/g/r>
- Press **h** and then transfer **Hwsetting(3)** by y-modem
 - hw_setting/0001-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
- Press **d** and then transfer **bootloader(2) -1** by y-modem
 - A01-Recovery-uda-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
- Press **g** to start recovery process
- Press **d** and then transfer **bootloader(2) -2** by y-modem
 - A01-Recovery-boot-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
- Press **b1** to start recovery process
- Press **b2** to start recovery process

Upgrade Boot loader

- This is for boot loader upgrade when current boot loader is workable
- Press **ESC** when booting up to enter U-Boot console
 - Realtek>
- Transfer bootloader with burning program(**1**) to DRAM
 - By USB
 - usb start
 - fatload usb 0:1 0x1500000 A01-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_spi.bin or RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - go 0x1500000
 - By tftp
 - tftp 0x1500000 A01-RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_spi.bin or RTD161x_hwsetting_BOOT_2DDR4_8Gb_s2666-nas-RTD16xx_emmc.bin
 - go 0x1500000

Rescue system

- This is used to install install.img onto RTD129x/RTD1619
- There are 2 ways to boot into rescue system
 - 1. use built-in rescue system
 - 2. use rescue system from USB or TFTP
- 1. For build-in rescue system, just press **TAB** when booting up, then the **built-in rescue system** is used
- Once booting into rescue system, put install.img in USB top directory and plug into RTD129x/RTD1619, the install process will start automatically

Rescue system

- 2. For rescue system from USB or TFTP, we should copy following 3 files to USB or TFTP directory

path: SDKRelease/OpenWRT-LEDE/target/linux/realtek/image/rkimagefile/workspace/rescue/

- 1. spi.ulimage
- 2. rescue.spi.dtb
- 3. rescue.root.spi.cpio.gz_pad.img

- **USB:** press **ESC** into U-Boot console mode with USB attached and then press '**gor**'
- **TFTP:** press ESC and then input following command
 - tftp \$kernel_loadaddr spi.ulimage;tftp \$fdt_loadaddr rescue.spi.dtb;tftp \$rootfs_loadaddr rescue.root.spi.cpio.gz_pad.img;go k
- put install.img in USB top directory and plug into RTD129x/RTD1619, the install process will start automatically

TFTP configuration

- TFTP is configurable in boot loader console mode
- Press **ESC** into console mode and then edit tftp related environment variables

```
Realtek> env set ipaddr 192.168.0.9
```

```
Realtek> env set serverip 192.168.0.56
```

```
Realtek> env set gatewayip 192.168.0.254
```

```
Realtek> env set netmask 255.255.255.0
```

```
Realtek> env save
```

- ping command can be used to test network

```
Realtek> ping 192.168.0.56
```



Dual Firmware Boot

```
| #fw fwpart_name : actual_size(dec) [(hex)]      / zone_size(dec) [(hex)] + 0x000001000000
+-----+
|   FREE SPACE :                                2719744 bytes [0x00298000] |
+-----+
| 2ndfw linuxKernel : 3698688 bytes [0x00387000] / 4128768 bytes [0x003f0000] |
|   Image.lzma.padding                           |
+-----+ 0x000000978000
| 2ndfw audioKernel : 311296 bytes [0x0004c000] / 393216 bytes [0x00060000] |
|   bluecore.audio.lzma.padding                  |
+-----+ 0x000000918000
| 2ndfw rescueRootFS : 1048576 bytes [0x00100000] / 1048576 bytes [0x00100000] |
|   rescue_rootfs.cpio.gz.padding               |
+-----+ 0x000000818000
| 2ndfw rescueDT : 49152 bytes [0x0000c000] / 49152 bytes [0x0000c000] |
|   rescue.dtb.padding                          |
+-----+ 0x00000080c000
| 2ndfw kernelDT : 49152 bytes [0x0000c000] / 49152 bytes [0x0000c000] |
|   normal.dtb.padding                         |
+-----+ 0x000000800000
|   FREE SPACE :                                413696 bytes [0x00065000] |
+-----+ 0x00000079b000
| 1stfw linuxKernel : 3698688 bytes [0x00387000] / 4128768 bytes [0x003f0000] |
|   Image.lzma.padding                           |
+-----+ 0x0000003ab000
| 1stfw audioKernel : 311296 bytes [0x0004c000] / 393216 bytes [0x00060000] |
|   bluecore.audio.lzma.padding                  |
+-----+ 0x00000034b000
| 1stfw rescueRootFS : 1048576 bytes [0x00100000] / 1048576 bytes [0x00100000] |
|   rescue_rootfs.cpio.gz.padding               |
+-----+ 0x00000024b000
| 1stfw rescueDT : 49152 bytes [0x0000c000] / 49152 bytes [0x0000c000] |
|   rescue.dtb.padding                          |
+-----+ 0x00000023f000
| 1stfw kernelDT : 49152 bytes [0x0000c000] / 49152 bytes [0x0000c000] |
|   normal.dtb.padding                         |
+-----+ 0x000000233000
```

Dual Firmware Boot

- There are 2 copies of firmware table and images (kernel, dtb, rescue rootfs...etc) installed in RTD129x/RTD1619
- Each firmware table has a sequence number (0-255)
- Boot loader will choose the latest (bigger) firmware table to bootup
- Once the latest firmware table or its content is corrupted, another firmware table will be chosen to bootup

Customize kernel boot arguments


Path: arch/arm/lib/bootm.c

Function: set_custom_boot_args()

- This function provides room to append programmable boot arguments.
- For example, the path of boot device might be "/dev/mmcblk0p0" or "/dev/mmcblk0p1", depending on circumstances. This can be done by adding conditional statement in this function to control boot arguments.
- The parameter "custom_boot_args" of this function is combined with kernelargs, and finally become part of kernel boot arguments.

Customize Bootflow: AC-Recovery

Shutdown: Normal Shutdown
AC Recovery: Enable/Disable
WOL: Enable/Disable



Customize Bootflow: AC-Recovery

■ Add Config

- ./Bootcode/U-Boot64/configs/rtd161x_qa_nas_rtk_defconfig
 - CONFIG_CUSTOMIZE_FEATURES=y
 - CONFIG_CUSTOMIZE_BOOTFLOW_1=y
 - CONFIG_CUSTOMIZE_BOOTFLOW_1_PHASE_1=y
- ./Bootcode/U-Boot64/common/customized_bootflow_rtd161x.c
 - #define PWR_KEY_IGPIO 2 (check you board before set)
 - #define ACRECOVERY_PATH FACTORY_HEADER_FILE_NAME"ACRECOVERY"
 - #define POWER_STAT_PATH FACTORY_HEADER_FILE_NAME"SHUTDOWN"
 - #define WAKE_ON_LAN_PATH FACTORY_HEADER_FILE_NAME"WAKEONLAN"
- ./rtd-1619-mmnas-megingjord-2GB.dts
 - rtk_iso_gpio: rtk_iso_gpio@98007100 {
 - wakeup-gpio-list = <&rtk_iso_gpio 2 0 1>; /*rtk_gpio gpio# direction value*/
 - /*direction: 0=input, 1=output; when direction=0=input, set value is useless */
 - wakeup-gpio-enable = <1>; /*0=disable, 1=enable*/
 - wakeup-gpio-activity = <0>;/*0=active low, 1=active high*/

Customize Bootflow: AC-Recovery

- Flag name: ACRECOVERY, SHUTDOWN, WAKEONLAN
- User can set AC-recovery, Shutdown & WOL enable/disable by factory tool in user space.
 - Enable: factory flag flag-name
 - Disable: factory unflag flag-name
- As flowchart, shutdown flag will be set to 0(disable) in every normal boot.
- When WOL is enable, be noted that WOL flag of gMAC also needs to set enable before shutdown.
 - `echo 1 > /proc/net/eth0/r8169/wol_enable`

Customize reserved memory for transcoding

- The following u-boot environment variables can be used to configure the reserved memory size for transcoding.
 - ion_media_heap0_size
 - ion_media_heap1_size
- Usage
 - Set a positive integer for the size of ion media heap 0 or 1 (unit: MB)
 - If the value exceeds the max. allowable memory size, it will prompt error message and reset the heap size to default value when booting into kernel.

```
Realtek> env set ion_media_heap0_size 199  
Realtek> env set ion_media_heap1_size 414
```

- Set the size of ion media heap 0 & 1 to zero
 - Disable transcode
 - Free the reserved memory for transcoding
 - The board has to restart for this change to take effect.

```
Realtek> env set ion_media_heap0_size 0  
Realtek> env set ion_media_heap1_size 0
```

Customize reserved memory for transcoding

■ Usage

- If the board is configured as pure NAS function (that is, there is no reserved memory for transcoding), attempting to set `ion_media_heap0_size` or `ion_media_heap1_size` will prompt error message and abort.

```
Realtek> env set ion_media_heap0_size 10
```

```
Error: env ion_media_heap0_size is reserved for  
adjusting the memory size of ion media heap  
memreserve for ion media heap is not found.
```

- To enable the transcode function again, delete the environment variable `ion_media_heap0_size` & `ion_media_heap1_size`.

Customize reserved memory for transcoding

